

Installation Instructions

Part no - 90000720

ATTIC FLOOR PENETRATION PLATE




The attic floor penetration plate is optional. When an attic floor penetration plate is used, the tightness of the vapour barrier has to be ensured.

The minimum distance of the attic floor penetration plate from the rear wall is 5 mm. The minimum distance of the attic floor penetration plate from the side walls is 15 mm.



NOTE

The attic floor penetration plate can only be used to make the ducts feed through airtight, however the unit cannot be hanged from the attic penetration plate. The only installation positions for the DV145 Adroit unit recommended are on the wall or on the floor.



© Airflow • We reserve the right to make changes without prior notice