

## Quick Start Guide – Purigo T


### Step 1

Place the unit into the desired position and fix it to the wall and level it by adjusting the feet.



### Step 2

Power the unit by plugging into the back of the product with a standard plug provided with the unit, switch the black power connector on by pressing down on the switch.



### Step 3

Press the speed control, and adjust the speed by turning clockwise.



### Step 4

Set the airflow you require by following the setting table on the operating manual, also available on [airflow.com](http://airflow.com)