

DS 2410 HL Hedgetrimmer



Documents

Engine

Starter assy and clutch

Air filter

Transmission

Carburettor

Hedgetrimmers




Illustration Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61370302R	Guard			Grigio; Grey	
2	4	3891036R	Screw				
3	6	3891048R	Screw				
4	1	61370085R	Crankcase assy				
5	3	3891051R	Screw				
6	2	3034029R	Bearing				
7	1	094600126	Tube				
8	1	61370189R	Cover			Rosso; Red	
9	1	3893060R	Screw				
10	1	56600036R	Complete muffler				
11	1	61370571R	Deflector				
12	1	3055112R	Spark plug				
13	1	58070011R	Gasket				
14	2	61370575R	Piston ring				
15	2	58070166BR	Ring				
16	5	61280044R	Plug				
17	1	61370605A	Piston assy Ø32				
18	1	61370606A	Complete cylinder Ø32				
19	1	61370254	Set roller cage and washer				
20	1	61370255	Gasket set				
21	1	58070045R	Shaft				
22	2	3050042R	Seal ring				
23	2	3025018R	Ring				

Illustration Starter Assy and Clutch




Illustration Starter assy and clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2501002R	Ignition coil				
2	1	50050127	Spring				
3	2	50160218BR	Spacer				
4	2	3891020R	Screw				
5	1	61370059R	Cable				
6	3	3891038R	Screw				
7	1	3893060R	Screw				
8	1	61370082BR	Handle				
9	2	3891053R	Screw				
10	1	61370574R	Starter rope				
11	1	61070036R	Spring				
12	1	61370022AR	Starter pulley				
13	1	61370237R	Spring				
14	1	61370023AR	Sprocket				
15	1	50160024	Screw				
16	1	61370231AR	Starter assy			Rosso; Red	
17	2	58070219R	Pawl				
18	2	61070039R	Spring				
19	1	58070221R	Clutch driver				
20	1	3064034R	Washer				
21	1	58070133R	Flywheel				
22	1	3912014R	Nut				
23	1	61070090R	Spring				
24	1	61370557	Complete clutch				
25	2	015000044R	Screw				
26	3	3891009R	Screw				
27	1	61370090R	Flange				
28	1	61170050CR	Clutch drum				
29	1	3024012R	Snap ring				
30	1	3025019R	Ring				
31	1	3035023R	Bearing				
32	1	61370524R	Starter case				
33	4	3891046R	Screw				
34	3	3893009R	Screw				
35	1	61370091AR	Cover				
36	4	3918007R	Washer				
37	1	61370525AR	Adaptor				
38	2	3914003R	Nut				
39	1	61370526AR	Adaptor				
40	1	3819031R	Washer				
41	1	61372171R	Set spacer				

Illustration Starter assy and clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
42	1	61370527R	Sleeve				
43	2	3916004R	Washer				

Illustration Air filter




Illustration Air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	58070025AR	Gasket				
2	1	61370001R	Insulator				
3	2	3891046R	Screw				
4	1	2318265R	Carburetor				
5	1	56570058R	Gasket				
6	1	3073017R	Tube				
7	1	61370552R	Tube				
8	1	61370553R	Tube				
9	1	61400367R	Breather valve				
10	1	4161211R	Bush				
11	1	2318817R	Air purge				
12	1	61372008AR	Filter support				
13	2	3891063R	Screw				
14	1	61370005R	Air filter				
15	1	61370008R	Knob				
16	1	61370258A	Filter cover kit				
17	1	61380112R	Tube				
18	1	61070006R	Gasket				
19	1	61200196AR	Gasket				
20	1	3059026	Band				
21	1	4098377R	Band				
22	1	094600450R	Fuel filter				
23	1	61372003R	Tank cap				
24	1	61370076R	Tank			Rosso; Red	
25	1	61370255	Gasket set				

Illustration Transmission





Illustration Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	4	3891038R	Screw				
2	1	61370052R	Clamp				
3	1	61370259	Handle				
4	5	3893060R	Screw				
5	1	61370043R	Lever				
6	1	61370260	Lever group				
7	1	61370044AR	Throttle lever				
8	1	61370198R	Spacer				
9	1	4162154B	Knob				
10	1	61290011R	Tube Ø24				
11	1	61170075R	Drive shaft				
12	1	61370270A	Complete handle				
13	1	61370032AR	Cable				
14	1	61370220AR	Throttle cable				
15	1	4160463AR	Single harness				
16	1	61370211R	Tool kit				
17	1	61370609	Labels kit				
18	1	61370134AR	Band				
19	1	3914003R	Nut				
20	1	3891053R	Screw				



■ 4 — KIT RIPARAZIONE
REPAIR KIT

Illustration Carburettor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318265R	Carburetor				
2	2	2318837	Adjust. screw				
3	2	2318867R	Caps-lock				
4	1	2318671	Repair kit				




Illustration Hedgetrimmers

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	3901061R	Screw				
2	1	3918007R	Washer				
3	1	58050016	Spring				
4	1	58050018	Handle				
5	3	3901062R	Screw				
6	1	3025026	Ring				
7	1	3024009R	Ring				
8	1	3035046AR	Bearing				
9	1	3034023AR	Bearing				
10	1	58050048R	Half case				
11	1	3901060	Screw				
12	1	3802003	Screw				
13	1	3901016	Screw				
14	1	58050005	Disk				
15	2	3037007	Bearing				
16	1	58050058A	Bevel gear set				
17	1	3024006R	Snap ring				
18	1	58050014R	Bushing				
19	1	58050015	Spring				
20	1	58050017R	Pipe				
21	2	61040071R	Cap				
22	1	3067006R	Bushing				
23	1	58052016R	Gear housing				
24	2	58040057R	Plate				
25	2	58040227AR	Connecting rod				
26	1	58050004R	Gasket				
27	2	3801057R	Screw				
28	1	3024008R	Snap ring				
29	1	58050011AR	Sprocket				
30	1	3025020	Snap ring				
31	2	3035009AR	Bearing				
32	1	008200282R	O-ring				
33	1	58050012	Pipe				
34	1	58052015R	Cover				
35	1	58040101R	Chain sprocket				
36	4	3980014R	Nut				
37	1	61370464R	Guard				EI6-10/14
38	2	58050021R	Blade				
39	1	58050013AR	Pin				
40	1	58040077AR	Gasket				
41	6	58040051R	Spacer				

Illustration Hedgetrimmers

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
42	1	58050023	Support				
43	4	3979021R	Screw				
44	1	61370463R	Guard				EI6-10/14
45	1	3914003R	Nut				
46	2	3918005R	Washer				
47	3	3819006R	Washer				
48	4	3057005R	Washer				
49	7	3960074R	Screw				
50	7	3819005R	Washer				
52	1	099900090R	Ring				