

LR 53 TKE COMFORT PLUS (K655LI) EURO 5 Lawnmower



Documents

Complete illustrated parts list

Crankcase

Crankcase cover

Shaft + piston

Reed valve kit

Ignition system

Carburetor

Air filter

Control lever

Muffler

Tank

Start motor assy




Illustration Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	66060398BR	Traction lever				
2	2	66070724R	Complete wheel				
3	1	66071044R	Traction cable				
4	1	66071090	Guard				
5	1	3914006R	Nut				
6	1	66110684	Handle				
7	1	66030038	Grommet				
8	1	66070100	Traction lever				
9	1	66071065R	Spring				
10	4	66030081R	Bearing				
11	1	66060421BR	Handlebar				
12	1	66070748	Axle kit				
13	2	66070944R	Tightening handle				
14	1	8202126R	Key				
15	2	66060231R	Band				
16	2	3910015R	Screw				
17	7	3914010R	Nut				
18	1	66070437R	Left sprocket				
19	1	66110753R	Shutter			Rosso; Red	
22	2	66060381BR	Pin				
23	1	66110609A	Kit spring				
24	1	66110026R	Deflector axle				
25	1	66070936AR	Deck			Grigio; Grey	
26	2	3916015R	Washer				
27	2	66070849R	Wheel cover				
28	1	3047027R	Belt				
29	1	66071084R	Pulley				
30	1	3801010R	Screw				
31	1	66070652R	Spring				
32	2	3064037R	Washer				
33	4	3024012R	Snap ring				
34	8	3916008R	Washer				
35	1	66070229	Rod				
36	1	66070436R	Right sprocket				
37	1	66070013C	Rear axle				
38	3	3806076R	Screw				
39	1	66070755B	Transmission				
40	5	011200035R	Screw				
41	1	66070018R	Lever				
42	1	66070060R	Wheel cover				
43	1	66030044	Spacer				

Illustration Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
44	1	66070036R	Spring				
45	2	66071063R	Complete wheel				
46	2	8202311R	Ring				
47	2	66070885R	Wheel cover				
48	1	66060010R	Roller				
49	1	66060316AR	Brake lever				
50	1	3906150R	Screw				
51	2	66060030R	Bushing				
52	1	66030276R	Engine break cable				
53	1	66060384R	Washer				
54	1	66030256R	Hub Ø22,2mm				
55	1	66070440R	Mulching blade				
56	4	66030081R	Bearing				
57	2	66030039	Plate				
58	4	3960031R	Screw				
59	6	3801022R	Screw				
60	2	66110781R	Support				
61	2	3045035R	Retainer washer				
62	2	3045034R	Retainer washer				
63	1	66060164CR	Complete throttle				
64	1	3906053	Screw				
65	3	66070228AR	Support				
66	1	66070233A	Guard kit				
67	1	66070903	Labels kit				
68	1	3026005R	Ring				
69	1	66071059R	Mulching cap				
70	1	66070744	Support set				
71	2	66070435R	Bushing				
72	2	3960072	Screw				
73	1	66070128R	Dashboard			sostituito da particolare intercambiabile ma di geometria differente /	
74	1	66070905	Grassbag kit				
75	1	66070522R	Cover				
76	1	66070466R	Lock			interchangeable part but with a different geometry	
77	2	66072047R	Frame				
78	1	66070521R	Shutter				
79	1	66070133R	Support				
80	1	66070876R	Grassbag				
81	1	66110795	Labels kit			Motore; Engine	
82	1	66070941R	Guard				
83	2	3960137R	Screw				
84	1	3044055R	Starting switch				

Illustration Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
85	1	66071046R	Safety key				

9*




Illustration Crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	4	L66150393	Screw				
2	1	L66151522	Cover				
3	1	L66151523	Gasket				
4	1	3055123R	Spark plug				
5	1	L66151524	Crankcase				
6	1	L66150409	Seal ring				
7	3	L66150464	Screw				
8	1	L66151525	Cap				
9	1	L66151570	Gasket set				
10	1	L66150410	Reed valve				
11	1	L66151526	Screw				
12	1	L66151527	Stud				
13	2	L66151528	Stud				
15	1	L66151975	Brake				
16	1	L66151531	Spring				
17	2	L66151532	Stud				
18	1	L66150453	Screw				
19	1	L66151533	Oil cap assy				
20	2	L66151534	Stud				
23	1	L66150456	Screw				

11*





Illustration Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	9	L66150817	Bolt				
2	1	L66151537	Couvercle subassment				
3	1	L66150462	Oil seal				
4	1	L66151538	Arbre régulateur				
5	1	L66150035	Rondelle				
6	1	L66150419	Joint				
7	1	L66150353	Goupille				
8	2	L66151539	Pivot				
9	1	L66151540	Regulateur				
10	1	L66150729	Screw				
11	1	L66151570	Gasket set				

2° serie / 2nd series



1° serie / 1st series





Illustration Shaft + piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151541	Piston ring set				BT5-88-05/23
2	1	L66151571	Piston assy				BT5-88-05/23
3	1	L66150342	Piston pin				
4	2	L66150372	Retainer washer				
5	1	L66151576	Connecting rod				
6	1	L66151577	Crankshaft				
7	1	L66151544	Slide				
8	1	L66152078	Piston ring set			Da utilizzare con pistoni /	BT5-88-05/23
9	1	L66152080	Piston assy				BT5-88-05/23




Illustration Reed valve kit

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66151545	Compensator				
2	1	L66151546	Plate				
3	2	L66150402	Equalizer rod				
4	2	L66151547	Slide				
5	1	L66151548	Camshaft assy				
6	2	L66150398	Spring holder				
7	2	L66150522	Valves spring				
8	2	L66150367	Seal				
9	1	L66150400	Intake valve				
10	1	L66151572	Reed valve kit				




Illustration Ignition system

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151551	Ignition coil				
2	1	L66150817	Bolt				
3	1	L66151969	Flywheel				
4	1	L66150376	Nut				
5	1	L66151550	Cover				
6	1	L66151968	Cover				
6*	1	L66151549	Starter assy			Avviamento manuale / Manual starter	
7	3	L66151976	Nut				
8	1	3075226R	Cover			Cover senza etichette / Cover without label	MO_0001_12/19

3*




Illustration Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151553	Gasket				
2	1	L66151981	Insulator				
3	1	L66151570	Gasket set				
4	1	L66151578	Carburetor				
6	1	L66150731	Shoe				




Illustration Air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151555	Tube				
2	1	L66151556	Filter support				
3	1	L66150715	Air filter				
4	1	L66151557	Filter cover				
5	2	004400959R	Nut				




Illustration Control lever

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151558	Rod				
2	1	L66151559	Throttle rod				
3	1	L66151560	Control lever				
4	1	L66151579	Spring				
5	1	L66151580	Complete lever				
6	1	L66150729	Screw				
7	1	L66150440	Clip				




Illustration Muffler

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151563	Gasket				
2	1	L66151564	Muffler				
3	1	L66151565	Cover				
4	2	L66150185	Nut				
5	1	L66151566	Control start				
6	2	L66150729	Screw				




Illustration Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151967	Complete tank				
2	1	L66151568	Tank cap				EI5-11/20
3	1	L66150439	Filter				
4	2	L66150456	Screw				
5	1	L66151569	Tube				
6	2	L66150435	Clip				





Illustration Start motor assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151970	Start motor assy				
2	1	L66151972	Starter relay				
3	1	L66151973	Bracket				
4	1	L66151974	Battery support				
5	1	L66151971	Starter cable				
6	1	3075273R	Battery charger				
7	1	3075272R	Battery				BT5-086-06/22
8	1	L66152070	Starter cable				
9	1	L66152071	Start motor assy				
10	1	3075272AR	Battery				
11	1	3075273AR	Battery charger				