



INSTALLATION AND OPERATING INSTRUCTIONS

In order to ensure correct operation and for your own safety, please read and observe the following instructions carefully before proceeding.

REGULATIONS – GUIDELINES

If the installation and operating instructions are observed, the product conforms to the applicable building regulations.

DELIVERY

The delivered package contains the Outdoor grille as well as a condensate discharge plate and mounting screws.

AREA OF APPLICATION

The Outdoor grille is intended to cover the wall sleeve (Part numbers: 90001004/90001007).

APPLICATION LIMITS OF STAINLESS STEEL

Stainless steel may discolour due to environmental impacts! Regular cleaning reduces the risk of discolouration.

INSTALLATION

Remove the components from the packaging only if you prepare to assemble it immediately, to avoid possible damage and contamination.

Align bezel frame as in Figure 1. and Figure 2 for the deeper outdoor grille version. Mark on the wall, drill and fix the frame with suitable screws (not included). Push the cover onto the cover frame so that the slope is directed downwards away from the wall and fix the cover to the cover frame with 4 screws.

The shipment must be checked for damage and correctness immediately upon delivery. If there is any damage, promptly report the damage by consulting the transport company. If complaints are not made within the agreed period, any claims could be lost.

STORAGE

The storage location must be water-protected and dust-free. Damages due to improper transportation, storage or commissioning must be verified and are not liable warranty.

CONDENSATE DRAINAGE

Condensation can form in the unit's heat accumulator during heating periods due to the heat recovery process. The condensate must be able to drain from the unit. A corresponding condensate drain gradient of 1-2° is ensured by the condensate wedge mounted to the wall installation sleeve. Alternatively, a core hole can be created with a gradient to the outside to ensure condensate drainage.

From the wall sleeve, the condensation is directed away towards the outdoor grille. The grille cover is designed with a slight slope at the bottom. This gradient is intended to direct the condensation away from the wall.

WARRANTY CLAIMS – EXCLUSION OF LIABILITY

If the instructions in this documentation are not observed, all warranty claims shall be excluded. This also applies to any liability claims extended to the manufacturer.

White outdoor panel/grille - Part number: 90001007

White outdoor panel/grille(deeper version) - Part number: 90001004 (In areas with high levels of air pollution and near the coast with high salt concentration in the air)

Figure 1: White outdoor panel




Figure 2: White outdoor panel (deeper version)





Figure 3: White outdoor panel



Figure 4: Dimensional drawing



Call: 01494 525252

Visit: airflow.com